PISTON AND CONNECTING ROD ASSEMBLIES

—Pistons ... 32
—Pistons and connecting rods—to remove ... 32
—to refit ... 32
—Gudgeon pin—to remove ... 33
—to fit ... 33
—to refit ... 33
—Big end bearing ... 33
—Connecting rods ... 33
—Little end bearing ... 34

PISTON RINGS

—Top compression rings ... 34
—Second compression rings ... 34
—Slotted oil control ring ... 34
—To fit ... 34

CYLINDER BLOCK

—Piston and cylinder bore grading ... 35
—To rebore and fit oversize pistons ... 35
—Cylinder liners ... 36
—Crankcase breather ... 36

CRANKSHAFT

—Main bearings ... 36
—Crankshaft end thrust ... 36
—To remove and refit, or replace ... 37

FLYWHEEL RING GEAR ... 38

FLYWHEEL CENTRE BEARING

—To remove and refit ... 38

ENGINE

—Removal procedures—cars and vans ... 38
—To remove leaving transaxle in vehicle—cars ... 39
—To remove with transaxle attached—cars ... 40
—To refit with, or without transaxle attached—cars ... 40
—To remove and refit with transaxle attached—vans ... 44
—Rear flexible mounting—to renew ... 40

ADDITIONAL INFORMATION

—Oil pump driven and driving gears ... 41
—Service replacement oil pumps ... 41
—Reclamation of tapped holes in engine castings ... 42