



THE ABOVE GAP GAUGES CAN BE MADE IN SERVICE WORKSHOPS FROM MILD STEEL BAR. IT IS IMPORTANT THAT THE GAUGES ARE CHAMFERED AT THE TOP AND REMAIN SQUARED AT THE BOTTOM AS SHOWN.

Fig. 17. Details of rear gap gauges