

# COOLING SYSTEM

## SECTION A

### CONTENTS

	Page
<b>BLEEDING THE SYSTEM</b> ... ..	3
<b>CLEANING THE SYSTEM</b> ... ..	7
—Cleaning procedure ... ..	7
—Cleaning the radiator exterior ... ..	7
<b>COOLING FAN ASSEMBLY</b> ... ..	9
—To remove ... ..	9
—To refit ... ..	10
<b>DESCRIPTION</b> ... ..	2
<b>DRAINING AND REFILLING THE SYSTEM</b> ... ..	2
—Draining the system ... ..	2
—Preparing the coolant ... ..	3
—Refilling the system ... ..	3
<b>FAN BELT ADJUSTMENT</b> ... ..	Refer to Section B
<b>PRECAUTIONS AGAINST FROST DAMAGE</b> ... ..	8
—Heaters ... ..	8
<b>RADIATOR</b> ... ..	6
—To remove ... ..	7
—To refit ... ..	7
<b>THERMOSTAT</b> ... ..	4
—To remove ... ..	4
—To refit ... ..	5
—Testing ... ..	5
<b>WATER PUMP ASSEMBLY</b> ... ..	10
—To remove ... ..	10
—To refit ... ..	11